

39. Check Nut (BSP)


SKU Code - CN



Sr. No.	SIZE	Ref Part No.
1	1/8"	CN18
2	1/4"	CN14
3	3/8"	CN38
4	1/2"	CN12
5	3/4"	CN34
6	1"	CN1

40. Hex Socket (BSP)

SKU Code - HS



Sr. No.	SIZE	Ref Part No.
1	1/8" x 1/8"	HS1818
2	1/4" x 1/8"	HS1418
3	1/4" x 1/4"	HS1414
4	1/4" x 3/8"	HS1438
5	1/4" x 1/2"	HS1412
6	3/8" x 3/8"	HS3838
7	3/8" x 1/2"	HS3812
8	1/2" x 1/2"	HS1212
9	3/4" x 3/8"	HS3438
10	3/4" x 1/2"	HS3412
11	3/4" x 3/4"	HS3434
12	1" x 3/4"	HS134
13	1" x 1"	HS11

41. Hex Head Plug (BSP)

SKU Code - HHP



Sr. No.	SIZE	Ref Part No.
1	1/8"	HHP18
2	1/4"	HHP14
3	3/8"	HHP38
4	1/2"	HHP12
5	3/4"	HHP34
6	1"	HHP1